




HAVSTA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.







2x




2x



2x




4x




2x


1



3x




18x



18x



15x



12x




4x

2




8x



8x




8x




8x




8x



2x



2x




4x

3




194867

6x




10091382

6x




123492

12x




110630

12x




10095420

12x




119030

12x




101345

10x



10040242

6x




190459

1x


10127303

3x


1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28





29







30




31





32







33



34



35






www.IKEA.com/secure-it






www.IKEA.cn/secure-it





36

English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.










38




39







40




41







42




43




44




45




46




47




48




49




50



51



52



53

