


SKRUVBY



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






150689

2x




126916

2x




150688

2x




147968

2x




158469

2x




121714

2x




13


327495




8x




8x




8x




12x




12x



12x




2x




4x


1




2




3




4




5




6




7




8




9




10




11




12




13




14





15




16







17




18




19



20



21






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



22




English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

A
Ø 8 mm (5/16")
1
2
3

B
Ø 8 mm (5/16")
1
2
3

C
Ø 3 mm (1/8")
1
2
3



23

