

SONGESAND



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






1



118331

14x



101345

16x



105248

4x



146114


24x



119252

119250


14x



153548


158568

5x




10093081

14x





10093082

14x






326949







1




2




3




4




5




6




7




8






9




10













14





15




16




17







19




20





21



22






23




24


4x





25





26









28








30



31





27 → 1

