




TONSTAD



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.







NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






106989

2x



10087223

2x




109567

2x



109049


2x



100823

4x

1




10046078

8x




113434

6x



120076

16x




190459

1x




10083447
10091526

4x



102553

4x



10096669

16x




118331

6x




101350

15x




106603

4x




151705

8x



151706

8x



159991

4x



10048881


16x

2



105811

4x




158473

1x



10127303

4x


1




2





3




4




5







7




8




9




10




11




12




13




14




15



16




17




18


4x




19

4x







20



21




22






www.IKEA.com/secure-it






www.IKEA.cn/secure-it





23

English



The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.









25




26




27




28




29




30




31




32



33



34



35

