


TONSTAD



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:




ALWAYS install anti-tip device provided.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

ALWAYS secure your television with an anchor device.


English

Read and follow each step of the instruction carefully.






1



100211

6x




109504

8x




146114

4x




151707

9x



151708

9x




10093081

5x




10093082

5x




10094664
10094662

8x




10092248
10092282

16x




133194
126918

2x




10094656

4x



10094681


4x




100001

1x


2




6x




8x




5x




6x




10x




10x




1x




1x




5x




4x




2x




2x




2x




2x



2x




2x




2x


1




2




3




4




5




6




7







9




10






11




12









14




15




16




17




18




19




20




21




22






23





24





25








↓
26









28



29



30





www.IKEA.com/secure-it




www.IKEA.cn/secure-it

31

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.



A

Ø 8 mm (5/16")

1

2
70 mm (2 3/4")

3

B

Ø 8 mm (5/16")

1

2
≈ 30 mm (≈ 1 1/4")

3




C

Ø 3 mm (1/8")






1


2
≈ 30 mm (≈ 1 1/4")

3







32







32



33






16x




10092248
10092282


34











37






38




39



40



41



42

