


IDANÄS



Design and Quality
IKEA of Sweden



English

WARNING!

Serious or fatal crushing injuries can occur from furniture tip-over. To reduce the risk of furniture tip-over:

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

Place heaviest items in the lower drawer.

Do not set TVs or other heavy objects on top of this product.

Never let children climb or hang on drawers, doors, or shelves.

Read and follow each step of the instruction carefully.

עברית

אזהרה!


נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית. על מנת להפחית את הסיכון של נפילת רהיטים:


יש להקפיד ולקבע את הריהוט לקיר באמצעות אביזרי קיבוע.


על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:




הניחו את הפריטים הכבדים ביותר במגירה התחתונה. הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.





אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים. קראו ופעלו בהוראות לפי כל שלב בהוראות.











10044733

4x

10044743

4x

1



100347

16x



101345

12x



118331
112996

12x




119253
118137

12x



10

2



100001

1x




100347

4x




101352

4x




102553

2x



131399
157732

4x




10093081

8x




10093082

8x




10093458

4x



151706

4x



151705

4x




17

3




10041120

8x




10047244

12x







119976

8x




31




150689

2x




126916

2x




150688

2x




147968

2x



121714

2x




23




363577



2




3



12x


118331
112996

4




2x


101345




5




6




7




8




9




10




11




12




15




16




17




18






19





20












23




24



25



26






www.IKEA.com/secure-it



www.IKEA.cn/secure-it




English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.


A




Ø 8 mm
(5/16")



1




2




70 mm
(2 3/4")

3




B




Ø 8 mm
(5/16")



1




2




≈ 30 mm
(≈ 1 1/4")

3




C




Ø 3 mm
(1/8")



1




2




≈ 30 mm
(≈ 1 1/4")


3









28




29






30




31





33



34

