


LASTARE



Design and Quality
IKEA of Sweden



English

WARNING!

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

Read and follow each step of the instruction carefully.

עברית

אזהרה!

ילדים נהרגו כתוצאה מנפילת רהיטים.

על מנת להפחית את הסיכון של נפילת רהיטים:

תמיד יש להתקין את אבזר הקיבוע.

לעולם אל תניחו טלוויזיה על מוצר זה.

לעולם אל תאפשרו לילדים לעמוד, לטפס או להיתלות על המגירות, הדלתות או המדפיים.

פתחו אך ורק מגירה אחת בכל פעם.



יש למקם את הפריטים הכבדים ביותר במגירות התחתונות.




קראו ופעלו בזהירות לפי כל שלב בהוראות.














	A	B	C
 www.IKEA.com/secure-it			
	Ø 8 mm (5/16") 	Ø 8 mm (5/16") 	Ø 3 mm (1/8") 






100214

12x



10124042

4x



10127224

4x




101449

4x



115339

2x




10095326

16x



10095315

16x




100001

1x




101345

12x




10005905

2x




10127151

4x




10071303

3x




10122530


3x




2x




2x




2x



2x





2x




2x


1




2




3




4








5




6




7



8



9





10

16x

10095326

10095315




90°





11


2x

150688







12




13







14



15



16






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



17

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

Ø 8 mm (5/16")

1

70 mm (2 3/4")

2

22

B

Ø 8 mm (5/16")

1

≈ 30 mm (≈ 1 1/4")

2

23


C

Ø 3 mm (1/8")


1

≈ 30 mm (≈ 1 1/4")


25





↕
18




19








18






19










18











20








19








21










1




2








22











23






24





25



24x

