



HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית


אזהרה


נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.


יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.





על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:





- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.













A



118331

24x




119976

12x



146114


36x



145718


159553

24x



101345


20x



119030


118224

48x



10052019

12x




10040242

6x




29




150689

2x




126916

2x



150688

2x




147968

2x



158469

2x



121714


2x



19


327495

1



151706
151708

14x




151705
151707

14x




146114

36x



10093081

6x




10093082

6x




101345

14x




153548
158568

2x




10040039
10051022

4x




10050771


2x



10050769

2x








10043622
10050475

6x


1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16






17













18




19









21



22




23






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



24

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.

A

Ø 8 mm (5/16")

1

2

70 mm (2 3/4")

3

B

Ø 8 mm (5/16")

1

2

≈ 30 mm (≈ 1 1/4")

3

C



Ø 3 mm (1/8")

1



2



≈ 30 mm (≈ 1 1/4")

3









25






⇕
26








26




27




28






2x




4x




29




30




31




32




33




34



35



36



37

