

ÄLSKVÄRD

Design Sarah Fager



Design and Quality
IKEA of Sweden

English

4

עברית

6

English

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

WARNING

- Do not use this product without reading the instructions for use first
- Stop using the product as soon as the child can sit or kneel or pull itself up
- Placing additional items in the product may cause suffocation
- Do not place the product close to another product, which could present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.

- **Do not use more than one mattress in the product**

Important safety information!

- Place the product on a horizontal floor
- Do not let young children play unsupervised in the vicinity of the product
- Make sure the product is locked in the fixed position when a child is unsupervised in it
- Tighten all assembly fittings properly before use. Check all fittings regularly and retighten as necessary. Care should be taken that no screws are loose, because a child could trap parts of the body or clothing (e.g. strings, necklaces, ribbons for babies' soothers, etc.), which would pose a risk of strangulation
- Thickness of the mattress shall be such that the height from the upper surface of the mattress to the upper edge of the frame is at least 200 mm (7 7/8"), see maximum mattress mark
- Be aware of the risk of burning cigarettes, open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the product
- Do not use the product if any part is broken, torn or missing
- Recommended size of suitable mattress is: 40x73 cm (15 3/4" x 28 3/4")

Care and clean

- Wipe clean with a cloth dampened in mild cleaner
- For textile follow the washing instructions on the product

חשוב! קראו בתשומת לב ושמרו לעיון בעתיד אזהרה

- אין להשתמש במוצר זה מבלי לקרוא תחילה את הוראות השימוש
 - הפסיקו להשתמש במוצר זה ברגע שילדכם מסוגל לשבת בכוחות עצמו או לכרוע ברך או להרים את עצמו למעלה
 - אין להציב בתוך המוצר פריטים נוספים שעשויים לגרום לחנק
 - אין להניח מוצר זה קרוב למוצר אחר אשר עשוי להוות סכנת חנק, לדוגמא, מיתרים, חוטי וילון וכו'.
 - אין להשתמש ביותר ממזרן אחד עם המוצר
- מידע בטיחות חשוב!
- יש להניח את המוצר על רצפה אופקית.
 - אין לאפשר לילדים קטנים לשחק בקרבת המוצר ללא השגחה.
 - הקפידו לנעול את המוצר במצב קבוע כאשר הילד נמצא בו ללא השגחה.

- יש לחזק את כל הברגים והחיבורים לפני השימוש. יש לוודא הידוק כל הברגים והחיבורים בקביעות ולחזק במידת הצורך. יש לדאוג לכך שלא יהיו ברגים רופפים, מכיוון שילד עלול להיתפס בחלק מהגוף או בפריט לבוש (למשל שרשרת, חוט בגדי תינוקות וכו'), דבר שעלול להוות סכנת חנק
- עובי המזרן יהיה כזה שהגובה מהמשטח העליון של המזרן עד לקצה העליון של המסגרת יהיה לפחות 200 מ"מ, ראו סימון גובה מזרן מרבי
- שימו לב לסכנות הנובעות מאש גלויה ומקורות חום אחרים כגון בעירת סיגריות, תנורים חשמליים ותנורי גז בסביבה הקרובה למוצר.
- אין להשתמש במוצר זה במידה וחלק כלשהו חסר, ניזוק או שבור.
- גודל מזרן מומלץ: 40x73 ס"מ

הוראות טיפול ותחזוקה

- נגבו במטלית טבולה בחומר ניקוי עדין
- עבור מוצרי טקסטיל עקבו אחר הוראות הכביסה על גבי המוצר

