

ANNONS



Design and Quality
IKEA of Sweden

English

4

עברית

4

English

Important!

If the pot/pan is provided with a glass lid, be careful when screwing the knob on to the lid. Do not screw on too tightly, because then the glass may break.

Care and cleaning

- Before using the cookware for the first time, wash, rinse and dry carefully.
- The cookware is dishwasher-safe. To prevent any marks left by limescale in the water, always wipe dry after washing. Spots and marks may be removed with a little vinegar diluted in lukewarm water.
- To prevent salt stains on the inside of your cookware, do not add salt to your food until the contents are boiling.
- Do not use steel wool or anything that may scratch the surface.
- The base is slightly concave when cold, but expands to flatten out when heated. Always leave cookware to cool before cleaning it. This allows the base to resume its shape and helps to prevent it from becoming uneven with use.

Good to know

- This cookware is suitable for use on all types of hobs.
- By placing the cookware on a hob with the same or a smaller diameter as the pot/pan you can save energy.
- Always lift the cookware when moving it on a glass ceramic hob to avoid the risk of scratching the hob.
- Bear in mind that the cookware gets hot during use. Always handle with pot holders.
- Never let the cookware boil dry, because the base becomes skew when overheated.
- The cookware is designed exclusively for cooking, not for storing food. Food that is stored in the cookware for a longer period may affect the surface and take on the taste of metal.
- The handle can be damaged by the flame when the cookware is used on a gas hob.
- If the handle or knob feels loose, tighten the screws with a screwdriver. Be careful when screwing the knob on to the lid. Do not screw on too tightly, because then the glass may break.
- If you have any problem with the product, contact your nearest IKEA store/Customer Service or visit www.ikea.com.

חשוב!

אם הסיר/מחבת מגיעים עם מכסה זכוכית, יש להזהר בעת הברגת הידיית אל המכסה. אין להדק אותה יותר מדי, כיוון שהדבר עלול לגרום למכסה להישבר.

הוראות ניקוי וטיפול

- לפני השימוש הראשון במוצר, מומלץ לנקות, לשטוף ולייבש אותו היטב.
- הסיר והקלחות בטוחים לניקוי במדיח כלים. את המחבת מומלץ לשטוף ידנית. כדי למנוע סימני אבנית על הכלים, מומלץ תמיד לנגב אותם לייבוש לאחר ההדחה. כתמים וסימנים ניתן להסיר באמצעות מעט חומץ מודול במים פושרים.
- אין להוסיף מלח למזון לפני הרתיחה, כדי למנוע כתמים בחלקו הפנימי של הכלי.
- בעת ניקוי הכלי אין להשתמש בצמר פלדה או כל תכשיר ניקוי העלול לשרוט את שטח הפנים.
- בסיס הכלים קעור מעט כאשר הם קרים, אך מתרחב ונעשה שטוח כאשר הם מתחממים. מומלץ להניח לכלי להתקרר לפני תהליך הניקוי. כך בסיס הכלי יוכל לחזור לצורתו המקורית ולא יתעקם לחלוטין לאחר שימוש ממושך.

טוב לדעת

- כלי זה מתאים לשימוש על כל סוגי הכיריים.
- השתמשו בכיריים בקוטר זהה או קטן יותר מאשר קוטר הכלי כדי לחסוך אנרגיה.
- כאשר מעבירים את הכלי על כיריים מזכוכית, מומלץ להרימו כדי למנוע שריטות מהכיריים.
- זכרו כי הכלי מתחמם מאוד בעת השימוש. בכל מגע עם הכלי מומלץ להשתמש בכפפות לתנור.
- אין להניח את הכלי על האש כאשר הוא ריק, או להשאירו עד לאידוי כל הנוזלים, כיוון שהחום הגבוה עלול להזיק לכלי.
- הכלי מיועד לבישול בלבד, לא לאחסון מזון. אחסון מזון בכלי לתקופת זמן ממושכת עלול להזיק לשטח הפנים של הכלי ולשוות למזון טעם מתכתי.
- יש לזכור כי שימוש בכלי על כיריים גז, עלול לגרום נזק לידיות.
- בכל שאלה או בעיה עם המוצר, אנא צרו קשר עם חנות IKEA/שירות לקוחות או היכנסו לאתר www.ikea.co.il