

BOCKÖN



Design and Quality
IKEA of Sweden

English

3

עברית

3

English

IMPORTANT:

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE
Follow all warnings and the assembly instructions carefully. DO NOT use the stand until fully assembled.



WARNING!

- Maximum weight load is 120 kg/265lb.
- Place the assembled stand on a flat, level surface a safe distance from other objects or obstacles.
- DO NOT install over concrete, asphalt, packed earth, or any other hard surface. A fall onto a hard surface can result in serious injury to the user.
- Children should not use a hammock without adult supervision.
- Instruct children never to walk or play close to a hammock when it is swinging.
- DO NOT get in or out of a hammock when it is swinging.
- DO NOT swing excessively in a hammock as this may cause the hammock to become unstable.
- Check fastenings regularly for tightness and retighten as necessary.
- DO NOT use the stand if any part is broken or missing. DO NOT substitute parts. Contact your nearest IKEA store for replacement parts.

Care instructions

Cleaning: Wipe clean with a mild soapy solution. It is not recommended to clean with a strong cleaner or an abrasive material because it may discolour or damage the surface.

Maintenance: The steel frame is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

Storing: If possible, store the stand in a cool, dry place indoors.

עברית

חשוב:

קראו בעיון ושמרו הוראות אלו לשימוש בעתיד
פעלו על פי האזהרות והוראות ההרכבה. אין להשתמש במעמד
טרם הורכב במלואו.



אזהרה!

- עומס מירבי: 120 ק"ג.
- הרכיבו את המעמד על משטח שטוח וישר ומקמו אותו במרחק בטוח מחפצים ומכשולים אחרים.
- אין להרכיב מעל בטון, אספלט אדמה קשה, או כל משטח קשה אחר. נפילה על משטח קשה יכולה לגרום לפציעה חמורה.
- אין לתת לילדים להשתמש בערסל ללא השגחה.
- הורו לילדים שאין ללכת או לשחק בקרבת הערסל בזמן שהוא בשימוש.
- אין לרדת מהערסל כל עוד הוא בתנועה.
- אין לנדנד את הערסל גבוה מדי מחשש להפיכתו.
- בדקו באופן שוטף שכל האביזרים מהודקים, והדקו במידת הצורך.
- אין להשתמש במעמד אם אחד מהחלקים פגום או הרוס. אין להחליף חלקים בחלקים אחרים. צרו קשר עם חנות IKEA הקרובה לבייתכם במידה ואתם זקוקים לחלקים חלופיים.

הוראות טיפול

הוראות ניקוי: נגבו באמצעות מטלית עם חומר ניקוי עדין. לא מומלץ לנקות עם חומר ניקוי חזק או חומר שוחק מכיוון שהם עלולים לגרום לשינוי בצבע או לפגוע במשטח.

תחזוקה: המסגרת מוגנת מפני היווצרות חלודה הודות לציפוי המגן. במידה ומסיבה כלשהי שכבת המגן תתקלקל, הפלדה אינה מוגנת ועלולה להיווצר חלודה. לתיקון הנזק, נקו וצבעו מחדש.

אחסון: אחסנו במקום קריר ויבש בתוך הבית, במידת האפשר.

