

# BROGRUND

Design H Preutz/N Karlsson

---

## ENGLISH

### Care and cleaning

Before using your mixer tap for the first time, unscrew the aerator and let water run through for about 5 minutes. Then screw it back on again.

For daily cleaning of your mixer tap, use a soft cloth dampened with water and, if necessary, a mild dish soap or detergent. Never use scouring powder, abrasive cleaners, steel wool, calcium-dissolving detergents or detergents that contain alcohol. Rinse with water and dry/polish with a clean dry cloth.

To remove calcium deposits, use ordinary white vinegar diluted in water and rinse with water.

We recommend unscrewing the aerator and cleaning it now and then. If it has calcium deposits, wash it with vinegar solution.

We recommend to clean any filters on the tap once a year by rinsing with clean water.

### Caution!

The water temperature is controlled by the position of the lever on the side of the tap. Be careful if you have recently used hot water since hot water may remain in the mixer tap, even if the lever is in the cold water position. Children should only use the mixer tap in the company of an adult.



Design and Quality  
IKEA of Sweden

# עברית

## הוראות טיפול

לפני שימוש ראשון בברז, יש לפתוח את הברז ולתת למים לזרום ללא סנן במשך 5 דקות לפחות על מנת למנוע היווצרות סתימות.

ניקוי הסוללה ושמירת הברק יעשו במים וסבון ובעזרת מטלית עדינה בלבד. כאשר מצטברת אבנית, יש לנקות באמצעות בד לח ועדין עם חומץ מהול במים.

אין להשתמש בצמר פלדה וכריות ניקוי קשות, חול ניקוי, חומצות, כוהל או כל חומר כימי אחר.

יש לפרק מדי פעם את הסנן ולנקותו בעדינות באמצעות שטיפה. יש לשטוף את הסנן בתמיסת חומץ במידה ונמצאה הצטברות אבנית

מומלץ לנקות את כל המסננים פעם בשנה על ידי שטיפה במים נקיים.

## זהירות!

טמפרטורת המים נשלטת באמצעות מיקום הידית בצד הברז. יש לנקוט במשנה זהירות לאחר שימוש במים חמים, גם כאשר הידית הועברה למצב מים קרים, זאת מכיוון שמים חמים עשויים להישאר בברז. אין להרשות לילדים להשתמש בברז ללא השגחת מבוגר.