

DUKTIG



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

Read this carefully and save for future use since it contains important information.

This calculator is intended for use by children over 3 years of age.

IMPORTANT!

- The included battery is NOT replaceable!
- Follow recycling instructions when removing the battery.
- Exhausted batteries are to be removed from the calculator. Follow instructions for recycling when disposing of exhausted batteries.
- When removing batteries, be sure to keep them away from small children since they pose a choking risk.
- Never try to take the battery apart or expose it to direct heat.
- If you do not wish to use the calculator for a longer period, remove the battery by following the recycling instructions to eliminate the risk of battery leakage.
- Do not store the calculator in extreme temperatures and do not leave it for long periods in direct sunlight as heat can damage the circuit board of the calculator.
- Make sure that the calculator is stored away from water, humidity and dust.
- Clean the calculator with a dry and clean cloth.

Instructions for use

Press the green button to start the calculator.

Press the red button to turn the calculator off.

To do calculations use a figure (0,1,2,3,4,5,6,7,8,9) and then press the desired method of calculation on the symbols (\div \times $-$ $+$). To get a result, press the $=$ symbol.



עברית

קראו מידע חשוב זה בתשומת לב ושמרו לעיון בעתיד.

מחשבון זה מיועד לילדים בגילאים מעל 3 שנים.

חשוב!

- הסוללה המצורפת אינה ניתנת להחלפה
- עקבו אחר הנחיות המחזור כאשר אתם מוציאים את הסוללה
- יש להוציא סוללות ריקות מהמחשבון. עקבו אחר הנחיות המחזור כאשר אתם משליכים את הסוללות הריקות.
- כאשר אתם מוציאים את הסוללות, יש לוודא שהן נמצאות הרחק מהישג ידם של ילדים קטנים כדי למנוע סכנת חניקה.
- לעולם אל תנסו לפרק את הסוללה או לחשוף אותה ישירות לחום.
- במידה ואינכם מעוניינים להשתמש במחשבון לתקופה ארוכה יותר, הוציאו את הסוללה תוך מעקב אחר הנחיות המחזור כדי להימנע מהסכנה של דליפת סוללה.
- אין לאחסן את המחשבון בטמפרטורות קיצוניות ואין להשאיר אותו באור שמש לזמן ממושך, מאחר וחום עלול לפגוע במעגל החשמלי של המחשבון.
- וודאו שהמחשבון מאוחסן הרחק ממים, לחות ואבק
- נקו את המחשבון במטלית יבשה ונקייה.

הוראות שימוש

- לחצו על הכפתור הירוק כדי להדליק את המחשבון
- לחצו על הכפתור האדום כדי לכבות את המחשבון
- לביצוע חישובים השתמשו במספר (0,1,2,3,4,5,6,7,8,9) ואז בחרו בשיטת החישוב הרצויה ע"י לחיצה על אחד הסימנים (+ - x ÷). לקבלת תוצאה לחצו על סימן =.

