



Design and Quality
IKEA of Sweden

English 3

עברית 4

English

IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

This product has been tested for domestic indoor and domestic outdoor use.

This furniture requires no maintenance. However, by keeping the furniture clean and storing it properly you can enjoy it year after year.

Clean: Wipe clean with a mild soapy solution. It is not recommended to clean plastic or metal furniture with a strong cleaner or an abrasive material because it may discolour or damage the surface.

Maintenance: Maintenance-free.

Storing: If possible, store your plastic furniture in a dry and cool place indoors. When stored outside, tilt the furniture and preferably use water-repellent covers. Make sure air can circulate to avoid moisture. In freezing temperatures, plastic can weaken and is not recommended for use.

Repair: The steel is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

חשיבות קראן בתשומת לב ושמרו לעיוון בעתיד

מווצר זה נבדק לשימוש ביתי בתחום הבית ומחוץ לו.

ההיט זה אינו מצריך תחזקה. עם זאת, שמירה על ניקיון הרהיט ואחסון ראוי יאפשרו לכם להנחות ממנה שנה אחר שנה.

ניקיון: נגבו באמצעות מטלית עם נוזל ניקוי עדין. לא מומלץ לנקיות ריהוט מפלסטיק או מתקת עם חומר ניקוי חזק או חומר שורט כיוון שהם יכולים לגרום לשינוי בצבע או לפגוע במשטח.

תחזקה: ללא תחזקה.

אחסון: במידת האפשר, יש לאחסן את ריהוט הגן מפלסטיק במקומות קרים ויבש בתחום הבית. אם מאחסנים בחוץ, יש להטוט את הרהיטים ולהשתמש בכיסויים דוחים. יש לוודא כי הרהיטים מאושרים כדי למנוע הצטברות מים. יש בטמפרטורות קפואות, פלסטיק עשוי להיחלש ואני מומלץ לשימוש.

תיקון: הפלדה מגנט מחלודה באמצעות ציפוי אבקה של צבע פלסטי. אם הציפוי מתפרק מסיבה כלשהי, הפלדה אינה מגנט ועלולה להיווצר חלודה. לתקן הנזק, נקנו וצבענו מחדש.