

FÖRNIMMA

English

Do not connect after each other in sequence.

To disconnect power, pull the plug.

Use only indoors in dry areas.

Do not overload the product.

Discard the product if damaged.

NOTE!

For adult use only. This is not a toy and is not intended for use by children.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.



Design and Quality
IKEA of Sweden

עברית

אין לחבר אחד אחרי השני ברצף.

לניתוק המוצר מהחשמל, הוציאו את התקע מן השקע.

לשימוש בתוך הבית ובאזורים יבשים בלבד.

אין ליצור עומס יתר על המוצר.

יש להשליך את המוצר במידה פגום.

שימו לב!

לשימוש מבוגרים בלבד. המוצר אינו צעצוע ואינו מיועד לשימוש ילדים.



סימן המיחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למחזור בהתאם לחוקים המקומיים. כשאתם ממיינים פסולת, אתם עוזרים להפחית את כמות האשפה המצטברת ולהקטין את ההשפעות המזיקות על האדם והסביבה. לקבלת מידע נוסף, פנו לחנות איקאה.