

HAMNÖN

Design Hanna Klarqvist



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

IMPORTANT:

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

Follow all warnings and the assembly instructions carefully. DO NOT use the hammock until fully installed.



WARNING!

- Maximum weight load is 120 kg/265lb.
- Install the hammock so that its lowest point is not more than 60 cm above the ground.
- DO NOT install over concrete, asphalt, packed earth, or any other hard surface. A fall onto a hard surface can result in serious injury to the user.
- ALWAYS check the hammock, ropes and fastenings for wear before each use.
- Children should not use the hammock without adult supervision.
- Instruct children never to walk or play close to the hammock when it is swinging.
- DO NOT get in or out of the hammock when it is swinging.
- DO NOT use the hammock if any part is broken, torn or missing. DO NOT substitute parts. Contact you nearest IKEA store for replacement parts.

Care instructions

Cleaning: Hand wash in warm water at 40°C (104°F). Avoid wetting the metal hooks. Place the hammock and rope in a large bucket or tub filled with warm water. Add mild liquid detergent and use a soft brush to work on any stains. Rinse thoroughly. Air-dry on a flat surface.

Storing: When not in regular use store the hammock in a cool, dry place indoors. At the end of the season wash and dry the hammock thoroughly before storing.

Additional warnings/instructions

Additional warnings/instructions when used with a hammock stand.

Assemble the hammock stand and attach HAMNÖN hammock following the assembly instruction provided.



WARNING!

- Place the assembled stand with hammock on a flat, level surface a safe distance from other objects or obstacles.
- Check fastenings regularly for tightness and retighten as necessary.
- DO NOT swing excessively in the hammock as this may cause the hammock to become unstable.
- DO NOT use the stand if any part is broken or missing. DO NOT substitute parts. Contact you nearest IKEA store for replacement parts.



עברית

חשוב:

קראו בעיון ושמרו הוראות אלו לשימוש בעתיד

פעלו על פי האזהרות והוראות ההרכבה. אין להשתמש בערסל טרם הורכב במלואו.



אזהרה!

- מקמו את המעמד והערסל שהרכבתם על משטח שטוח ובמרחק בטוח מחפצים ומכשולים אחרים. בדקו באופן שוטף שכל האביזרים מהודקים, הדקו במידת הצורך.
- אין לנדנד את הערסל גבוה מדי מחשש לכך שהערסל יהיה לא יציב.
- אין להשתמש במעמד אם אחד מהחלקים פגום או הרוס. אין להחליף חלקים בחלקים אחרים. צרו קשר עם חנות IKEA הקרובה לבייתכם במידה ואתם זקוקים לחלקים חלופיים.

- עומס מרבי: 120 ק"ג.

- הרכיבו את הערסל כך, שהנקודה הנמוכה ביותר שלו ממוקדת במרחק של 60 ס"מ מהקרקע, לכל היותר.
- אין להרכיב את הערסל מעל בטון, אספלט אדמה קשה, או כל משטח קשה אחר. נפילה על משטח קשה יכולה לגרום לפציעה חמורה.
- בדקו באופן שוטף את הערסל, החבלים והחיבורים לפני השימוש בו.
- אין לתת לילדים להשתמש בערסל ללא השגחה.
- הורו לילדים שאין ללכת או לשחק בקרבת הערסל בזמן שהוא בשימוש.
- אין לרדת מהערסל כל עוד הוא בתנועה.
- אין להשתמש בערסל במידה וחלק כלשהו ממנו הינו שבור, קרוע או חסר. אין להחליף חלקים בחלקים אחרים. צרו קשר עם חנות IKEA הקרובה לבייתכם במידה ואתם זקוקים לחלקים חלופיים.

הוראות טיפול

הוראות ניקוי: שטפו ידנית במים חמים ובטמפרטורה של 40°C צלסיס. הימנעו מלהרטיב את מוט העץ וההווים המתכתיים. הניחו את הערסל והחבל בדלי גדול או אמבט ומלאו במים חמים. הוסיפו חומר ניקוי עדין והשתמשו במברשת רכה לניקוי הכתמים. יש לשטוף ביסודיות ולאוויר על משטח שטוח.

אחסון: כאשר הערסל אינו בשימוש, אחסנו אותו במקום קריר ויבש בתוך הבית. בסוף העונה, שטפו את הערסל ויבשו אותו היטב לפני אחסונו.

אזהרות/הנחיות נוספות

אזהרות/הנחיות נוספות לשימוש עם מעמד לערסל. הרכיבו את המעמד לערסל ואת ערסל HAMNÖN בהתאם להוראות ההרכבה המצורפות.