


IKEA 365+



Design and Quality
IKEA of Sweden

English	4
עברית	6



English

Before using for the first time

Before using the coffee/tea maker for the first time, wash, rinse and dry carefully.

Instructions for use

1. Remove the plunger and warm the glass coffee pot by rinsing it with hot water.
2. Add ground coffee (preferably coarsely-ground) or tea.
3. Top up with water to a level just below the spout. For the very best flavour, use water which is just a degree or so below boiling. Stir.
4. Put the plunger in place, but do not press the filter down. Leave it under the lid for a minute or two, to give time for the coffee/tea and water to mix.
5. Hold the handle and slowly press the plunger down.
6. If the plunger becomes difficult to push down, remove it from the pot, and then slowly plunge down again vertically.

Cleaning

- The glass and metal parts are dishwasher safe. The bamboo knob and the cork coaster should be washed by hand.
- The coffee/tea maker can be taken apart as shown in the picture.

Important!

- Glass is a fragile material and should be handled with care at all times.
- Never use a glass container that has scratches, cracks or other visible damages, since this may weaken the material and cause the glass to break. Therefore, always check for damage to the glass before use. Avoid bumping the glass container against objects that could cause damage, for example a dishwasher, worktop or cabinet.
- The product must not be used by children and should be kept out of the reach of children. The glass container may contain boiling water which can cause burns.

- The glass container should not be exposed to great variations in temperature since this may cause the glass to crack. Therefore, never place a hot glass container on a cold or wet surface.
- The coffee/tea maker is not safe to use on a hot plate, gas ring or ceramic hob.

עברית

לפני השימוש הראשון

נקו היטב, שטפו והניחו לייבוש את הכלי להכנת קפה/תה לפני השימוש הראשון.

הוראות שימוש

1. הסירו את הבוכנה והמסננת וחממו את קנקן הזכוכית באמצעות זרם מים חמים.
2. הוסיפו קפה טחון (רצוי בטחינה גסה) או תה.
3. מזגו מים עד למעט מתחת לזרבובית. לקבלת התוצאות הטובות ביותר, הוסיפו מים בדרגת חום קרובה במעלה אחת לרתיחה. בחשו.

4. הכניסו את הבוכנה והמסננת, אך אל תלחצו על הפילטר כלפי מטה בשלב זה. סגרו את המכסה לדקה או שתיים כדי לתת למים ולקפה להתערבב היטב.
5. לחצו על הידית באיטיות והורידו את המסננת כלפי מטה.
6. במקרה ואתם מתקשים בלחיצה על הבוכנה. הסירו את הבוכנה והמסננת. לחצו שוב על הידית באיטיות כלפי מטה והקפידו לשמור על ידית ישרה ככל האפשר.

הוראות ניקוי וטיפול

- הזכוכית וחלקי המתכת מתאימים לניקוי במדיח כלים. יש לשטוף ידנית את ידית הבמבוק ותחתית השעם.
- ניתן לפרק את הכלי להכנת קפה/תה כפי שנראה בתמונה.

חשוב!

- זכוכית היא חומר שביר ויש לטפל בזהירות בכל עת.
- אין להשתמש בכלי מזכוכית עם שריטות, סדקים או נזק גלוי אחר, מכיוון שהדבר עלול להחליש את החומר ולגרום לשבירת הזכוכית. הקפידו לבדוק את תקינות המוצר לפני השימוש. הימנעו מלהיתקל במיכל הזכוכית בחפצים העלולים לגרום נזק, למשל מדיח כלים, משטח עבודה או ארון.
- אין לאפשר שימוש במוצר על-ידי ילדים ויש לשמור אותו מחוץ להישג ידם של ילדים. מיכל הזכוכית עשוי להכיל מים רותחים העלולים לגרום לכוויות.
- אין לחשוף את כלי הזכוכית לשינויים קיצוניים בטמפרטורה מחשש להיסדקות הזכוכית. לכן, אין להניח מיכל זכוכית חם על משטח קר או רטוב.
- מכונת הקפה/תה אינה בטוחה לשימוש על גבי פלטה חמה, כיריים גז או כיריים קרמיות.