

KANTNÅL

English

Before first use

- Wash with washing-up liquid and rinse with water before using for the first time.

How to use

- Grease the mould with cooking fat for easier release of the cake.
- Fill the mould to 2/3 of its content. If the mould is placed on a baking sheet it will be easier to put it in the oven without spilling or burning yourself.
- Bear in mind that sharp objects can damage the silicone. Only use plastic utensils.
- The silicone mould withstands temperatures up to 250°C (480°F).
- The silicone mould is dishwasher-safe and microwave-safe.



Design and Quality
IKEA of Sweden

עברית

לפני השימוש הראשון

- יש לנקות בחומר ניקוי ולשטוף היטב במים לפני השימוש הראשון.

אופן השימוש

- יש לשמן את התבנית בשמן בישול כדי שהעוגה תחליק ממנה בקלות.
- מלאו את התבנית כדי שני שליש מקיבולתה. כדאי להניח את התבנית על נייר אפיה, שכן כך יהיה לכם קל יותר להניח אותה בתנור מבלי לטפטף ומבלי להסתכן בכוויה.
- השתמשו בכלי פלסטיק בלבד, שכן חפצים חדים עלולים לפגוע בסיליקון.
- תבנית הסיליקון מסוגלת לעמוד בטמפרטורות של עד 250 מעלות צלזיוס.
- התבנית ניתנת לניקוי במדיח כלים ולחימים במיקרוגל.