

# MÅLA



Design and Quality  
IKEA of Sweden

## English

### How to use

Washable; marks from the felt-tip pens can be washed from most surfaces and materials using soap and lukewarm water, however, it's important to remove any marks as soon as they occur.

The felt-tip pen does not dry out if left uncapped for up to 3 days. For long-lasting performance, however, replace the cap immediately after each use.

## עברית

### כיצד להשתמש

ניתן לשטיפה; סימנים מטושים דקים ניתנים לשטיפה מרוב המשטחים והחומרים באמצעות סבון ומים פושרים. עם זאת, חשוב להסיר כתמים מיד לאחר היווצרותם.

ניתן להשאיר את הטוש הדק ללא מכסה עד שלושה ימים ללא חשש של התייבשות. לתוצאות ארוכות טווח יש להשיב את המכסה לטוש מיד לאחר כל שימוש.