

MÅLA



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

How to use

For use on whiteboards; the lifespan of the pen will decrease if used on paper.

Store horizontally. If the colour becomes less intense, store the pen vertically with the tip pointed down for 12 hours and the colour will revive.

The whiteboard pen will leave permanent marks on most surfaces and materials, however, immediately washing the area with a stain remover may give good results.

Always protect children's clothes and the surrounding floor etc.

עברית

כיצד להשתמש

לשימוש על לוח מחיק; אורך חיי הטוש יתקצר בשימוש על נייר.

אחסנו במאוזן. במידה והצבע דוהה מעט, אחסנו את הטוש במאונך כשהקצה מופנה מטה למשך 12 שעות, והצבע יתחדש.

טוש ללוח לבן עלול להשאיר כתמים קבועים על רוב המשטחים והחומרים. יחד עם זאת, שטיפה מיידית של האזור במסיר כתמים עשויה להביא לתוצאות טובות. יש להקפיד ולשמור על בגדי הילדים ועל הרצפה מסביב, וכו'.