

PARASOLL



Design and Quality
IKEA of Sweden



English	4
עברית	6

English

Get started

PARASOLL door/window sensor has a magnetic strip that detects when a door, window or cabinet is opened.

You can connect it to smart lighting to illuminate a space when the sensor is open or use DIRIGERA hub and IKEA Home smart app to receive notifications if the sensor opens while you are away from home.

Get started without DIRIGERA hub

1. Open the back of the sensor, insert 1 x AAA battery and locate the  Pairing button.
2. Make sure the smart bulb you want to connect is set up and switched on.
3. Hold the sensor less than 5 cm away from the smart bulb you want to connect.
4. Press and hold the  Pairing button on the sensor for at least 10 seconds. A red LED light on the sensor will flash and the smart bulb will blink twice when pairing is complete.
5. Use the assembly instructions to mount the sensor in the chosen location and test it by opening and closing the magnetic strips.

Get started with DIRIGERA hub

Open the back of the sensor, insert 1 x AAA battery and close it again. Use the assembly instructions to mount the sensor, then download the IKEA Home smart app and follow the instructions on screen.

IKEA Home smart app

For Apple devices, download the app using the App Store. For Android devices, download the app using Google Play store.

Get to know your product

The sensor can be connected to smart lighting to illuminate a space when the magnetic strip on the sensor is open. This is perfect for lighting hard-to-reach areas, such as basements or storage rooms.

Connecting more smart lights

1. Open the back of the sensor and locate the Pairing button.
2. Make sure the smart bulb you want to connect is set up and switched on.
3. Hold the sensor less than 5 cm away from the smart bulb and press and hold the Pairing button for at least 10 seconds. A red light on the sensor will flash and the bulb will pulse when pairing is complete.

Good to know

- You can connect a maximum of 10 smart lights to a single sensor.
- The sensor has a magnet at each end, so there is no right or wrong way round. Make sure the sensor and magnetic strip are mounted within 5 mm of each other.
- An LED light will blink twice when the sensor is opened, and blink once when the space is closed again.
- The sensor can be mounted outdoors if the environment is sheltered from heavy rain.

Battery care

When the battery gets low, a red LED light on the sensor will blink 3 times. DIRIGERA hub and IKEA Home smart app users can view battery status in the app and receive notifications when the battery starts to run out.

Changing the battery

Open the battery lid and replace with a new AAA/HR03 battery.

Recommended battery type:

1 x IKEA LADDA 750 (AAA/HR03, 1.2V, 750mAh, Ni-MH) (not included)

Factory reset

To reset and remove all connected products, quick-press the Pairing button 4 times within 5 seconds. A LED light strip on the sensor will blink and then shine continually once the reset is complete.

WARNING!

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

IMPORTANT!

- The sensor is for indoor use only and can be used in temperatures ranging from 0°C to 45°C (32°F to 113°F).
- Do not leave the sensor in direct sunlight or near any heat source, as it may overheat.
- The range between the sensor and the receiver are measured in open air.
- Different building materials and placement of the units can affect the wireless connectivity range.
- The sensor will not work if mounted on a magnetic metal surfaces.

Care instructions

To clean the product, wipe with a soft cloth moistened with a little mild detergent. Use another soft, dry cloth to wipe dry. Never use abrasive cleaners or chemical solvents as this can damage the product.

Technical data

Model: PARASOLL door/window sensor

Type: E2013

Input: 1.2V, 1 x AAA/HR03 LADDA battery

Range: 10 m in open air.

For indoor use only

Operating frequency: 2400-2483.5 MHz

Output power: 9 dBm (EIRP)

IP-class: IP44



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

חיישן PARASOLL כולל פס מגנטי המזהה פתיחה של דלת, חלון, או ארון.

ניתן לחבר אותו לתאורה חכמה כדי להאיר חלל מסוים בעת הפתיחה או להשתמש ברכות רשת DIRIGERA (hub) ואפליקציית IKEA Home smart כדי לקבל התראות כשהדלת/חלון נפתחים בזמן שאתם מחוץ לבית.

הפעלה ללא רכות רשת (DIRIGERA hub)

1. פתחו את המכסה בגב החיישן, הכניסו סוללה 1 x AAA מצאו את כפתור הצימוד.
2. ודאו שהמנורה החכמה שברצונכם לחבר מוגדרת ודלוקה.
3. החזיקו את החיישן בטווח של פחות מ-5 ס"מ מהנורה החכמה שברצונכם לחבר.
4. לחצו והחזיקו את כפתור הצימוד למשך 10 שניות לפחות. נורית לד אדומה תהבהב בחיישן והנורה החכמה תהבהב פעמיים, כאשר תהליך הצימוד יושלם.
5. השתמשו בהוראות ההרכבה כדי להתקין את החיישן במקום הרצוי ובדקו שהוא פועל כראוי על ידי פתיחה וסגירה של הפסים המגנטיים.

הפעלה עם רכות רשת (DIRIGERA hub)

פתחו את המכסה בחלק האחורי של החיישן, הכניסו סוללת 1 x AAA וסגרו את המכסה. השתמשו בהוראות ההרכבה להתקנת החיישן, לאחר מכן הורידו את אפליקציית IKEA Home smart ועקבו אחר ההוראות במסך.

אפליקציית IKEA Home smart

עבור מכשירי Apple, הורידו את האפליקציה מ-Apple Store. עבור מכשירי Android, הורידו את האפליקציה מחנות Google Play. שימו לב: במידה וברשותכם שער TRÅDFRI, אנא השתמשו באפליקציית IKEA Home smart 1.

אופן השימוש

ניתן לחבר את החיישן לתאורה חכמה כדי להאיר חלל מסוים כאשר הפס המגנטי בחיישן פתוח. פתרון מושלם להארת אזורים לא נגישים, כמו מרתפים או חדרי אחסון.

חיבור תאורה חכמה נוספת

1. פתחו את המכסה בגב החיישן ומצאו את כפתור הצימוד.
2. ודאו שהמנורה החכמה שברצונכם לחבר מוגדרת ודלוקה.
3. החזיקו את החיישן במרחק של פחות מ-5 ס"מ מהנורה החכמה ולחצו לחיצה ארוכה במשך 10 שניות על כפתור הצימוד. נורית לד אדומה תהבהב בחיישן והנורה תהבהב פעמיים, כאשר תהליך הצימוד יושלם.

טוב לדעת

- ניתן לחבר עד 10 מקורות תאורה חכמים לחיישן אחד.
- לחיישן מגנט בכל קצה, כך שהכיוון אינו חשוב. ודאו שהחיישן והפס המגנטי מותקנים במרחק של 5 מ"מ אחד מהשני.
- נורת לד תהבהב פעמיים בעת פתיחת החיישן ופעם אחת כאשר החלל ייסגר שוב.
- ניתן להתקין את החיישן בחוץ אם הסביבה מוגנת מפני גשם כבד.

טיפול בסוללה

במידה והסוללה חלשה, נורית לד אדומה בחיישן תהבהב 3 פעמים. ניתן לראות את מצב הסוללה ולקבל התראות כשהסוללה מתרוקנת באמצעות רכות רשת (DIRIGERA hub) ואפליקציית IKEA Home smart.

החלפת הסוללה

פתחו את מכסה הסוללה והחליפו אותה בסוללת AAA/HR03 חדשה.

סוגי סוללות מומלצים:

(לא כלול) (1x IKEA LADDA 750 (AAA/HR03, 1.2V, 750mAh, Ni-MH

איפוס להגדרות יצרן

לאיפוס והסרת כל המוצרים המחוברים, לחצו במהירות על כפתור הצימוד 4 פעמים (בתוך 5 שניות). נורית הLED בפס המגנטי של החיישן תהבהב, ולאחר מכן תאיר בקביעות כשתהליך האיפוס יושלם.

אזהרה!

החלפת הסוללה שלא בהתאם להוראות עלולה לגרום לפיצוץ. יש להשליך סוללות משומשות בהתאם להנחיות

מידע חשוב!

- החיישן מיועד לשימוש בתוך הבית בלבד וניתן להשתמש בו בטמפרטורות הנעות בין 0°C - 45°C מעלות צלזיוס.
- אין להשאיר את החיישן חשוף לאור שמש ישיר או בקרבת מקור חום כלשהו, מכיוון שהוא עלול להתחמם יתר על המידה.
- טווח הקישוריות בין החיישן למקלט נמדדים באוויר הפתוח.
- חומרי בניין שונים ומיקום עשויים להשפיע על טווח הקישוריות האלחוטית.
- החיישן לא פועל על משטחי מתכת מגנטיים.

הוראות טיפול

על מנת לנקות את המוצר, נגבו במטלית רכה ולחה. נגבו ליבוש במטלית רכה ויבשה
אין להשתמש בחומרי ניקוי כימיים חזקים מאחר והם עלולים לגרום נזק למוצר

מפרט טכני

דגם: חיישן דלת/חלון PARASOLL

סוג: E2013

מתח: 1.2V, 1x סוללה 1.2V, 1x AAA/HR03 LADDA

טווח: 10 מ' באוויר הפתוח.

לשימוש בתוך הבית בלבד

תדר הפעלה: 2400-2483.5 MHz

הספק: 9 (EIRP) dBm

קטגוריית IP: IP44

סימן המחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למחזור בהתאם לחוקים המקומיים. באמצעות הפרדת מוצר זה מן הפסולת הביתית, תעזרו להפחית את כמות הפסולת המועברת למשרפות או מטמנות ולמזער את ההשפעה השלילית על בריאות האנשים והסביבה. לקבלת מידע נוסף, אנא צרו קשר עם חנות איקאה הקרובה לביתכם.



