

RIKLIG



Design and Quality
IKEA of Sweden

English

4

עברית

6

English

Cleaning

Wash, rinse and dry the teapot before using it for the first time. The teapot is dishwasher-safe. The lid and the insert should be washed by hand, however, to prevent dulling of the plastic. Do not use steel wool or abrasives to clean the pot as this may scratch the glass. After cleaning, wipe the teapot dry to avoid lime stains from the water.

How to use the teapot

Put the desired amount of tea in the insert placed in the teapot. Slowly pour hot water through the strainer into the teapot. The teapot is not safe to use in the oven or on a hot plate, gas ring or ceramic hob.

Important!

- Glass is a fragile material and should be handled with care at all times.
- Never use a glass container that has scratches, cracks or other visible damages, since this may weaken the material and cause the glass to break.

Therefore, always check for damage to the glass before use. Avoid bumping the glass container against objects that could cause damage, for example a dishwasher, worktop or cabinet.

- The product must not be used by children and should be kept out of the reach of children. The glass container may contain boiling water which can cause burns.
- The glass container should not be exposed to great variations in temperature since this may cause the glass to crack. Therefore, never place a hot glass container on a cold or wet surface.

עברית

הוראות ניקוי

שטפו ויבשו את הקומקום לפני השימוש הראשון. הקומקום בטוח לניקוי במדיח כלים. יש לשטוף ידנית את המכסה והחלק הפנימי, על מנת למנוע נזקים בחלקי הפלסטיק. אין להשתמש בצמר פלדה או בחומרי קרצוף בעת הדחת הקומקום על מנת למנוע שריטות בחלקי הזכוכית. לאחר הניקוי, נגבו את הקומקום לייבוש על מנת למנוע כתמי אבנית.

אופן השימוש בקומקום

שימו כמות רצויה של תה בפילטר הפנימי. מזגו מים רותחים דרך המסננת אל הקומקום. הקומקום אינו בטוח לשימוש בתנור, על פלטת חימום, כיריים גז או כיריים קרמיות.

חשוב!

- זכוכית היא חומר שביר ויש לטפל בזהירות בכל עת.
- אין להשתמש בכלי מזכוכית עם שריטות, סדקים או נזק גלוי אחר, מכיוון שהדבר עלול להחליש את החומר ולגרום לשבירת הזכוכית. הקפידו לבדוק את תקינות המוצר לפני השימוש. הימנעו מלהיתקל במיכל הזכוכית בחפצים העלולים לגרום נזק, למשל מדיח כלים, משטח עבודה או ארון.

- אין לאפשר שימוש במוצר על-ידי ילדים ויש לשמור אותו מחוץ להישג ידם של ילדים. מיכל הזכוכית עשוי להכיל מים רותחים העלולים לגרום לכוויות.
- אין לחשוף את כלי הזכוכית לשינויים קיצוניים בטמפרטורה מחשש להיסדקות הזכוכית. לכן, אין להניח מיכל זכוכית חם על משטח קר או רטוב.

