

ROTHULT



Design and Quality
IKEA of Sweden

English

4

עברית

6

Keyless lock features

- Keyless lock. 2 Master keycards included.
- Possibility to use an extra card supporting NFC/RFID
- Warning signal when the batteries run low.

Instructions for use

- Install the lock and lock-plate according to the assembly instructions for your product.
- Check so that the 2 Master keycards can operate the lock after inserting the batteries.
- We recommend that you put one of the Master keycards in a safe place as an spare key.

Note - there are no spare cards at IKEA.

Using Other Cards

- Extra card (for ex. library card, membership card and public transport card) supporting NFC/RFID might be possible to use as a key.
- The door/drawer should be open when introducing an extra card, unlock with your Master keycard and introduce the extra key by holding it against the reading area.

- If you hold other cards against the reading area, you will hear three short signals.
- Only one extra card can be used at the time.
- You can always open the lock with your Master keycard, without removing extra card access.

Good to know

- The Master keycard can lock and unlock the unit at any time.
- The unit will sound if wrong card is used.
- If you loose your extra card you can reset lock by removing batteries.
- If the batteries run low a warning signal will sound from time to time.
- If they are not replaced in time the lock will automatically open and stay open. Batteries will last for approx. 17 months when using 3 AAA 900mAh batteries and open/close the lock 3 times per day.
- Storage temperature: -20°C to 50°C.
- Operating temperature: 5°C to 45°C.

Save these instructions for future use.

Reset:

Remove batteries.

WARNING

This product may only be supplied by the following AAA/HR03 type batteries: LADDA 900 (1.2V, 900mAh, Ni-MH), LADDA 500 (1.2V, 500mAh, Ni-MH), Alkaline or Carbon-Zink batteries.

Do not mix batteries of different capacities, types or date stamps.

Product servicing

Do not attempt to repair this product yourself.

Technical data:

Type: E1778 ROTHULT

Input: 3 x AAA/HR03 size batteries

Indoor use only

Operating frequency: 13.56 MHz

Output power: Max 50.9 dBµV at 3m

Manufacturer: IKEA of Sweden AB

Address:

Box 702, SE-343 81 Älmhult, SWEDEN



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

- אם אתם מחזיקים כרטיסים אחרים על אזור הקריאה, תשמעו שלושה אותות קצרים.
- ניתן להשתמש רק בכרטיס אחד נוסף בכל פעם.
- תמיד תוכלו לפתוח את המנעול עם כרטיס מפתח המאסטר שלכם, ללא הסרת הגישה לכרטיס נוסף.

טוב לדעת

- כרטיס מפתח המאסטר יכול לנעול ולפתוח את היחידה בכל זמן.
- היחידה תשמיע צליל אם נעשה שימוש בכרטיס הלא נכון.
- אם תאבדו את הכרטיס הנוסף שלכם תוכלו לאפס את המנעול על ידי הסרת הסוללות.
- אם הסוללות חלשות יישמע צליל אזהרה מעת לעת.
- אם הן לא מוחלפות בזמן, המנעול ייפתח באופן אוטומטי וישאר פתוח. הסוללות יחזיקו ל-17 חודשים לערך בשימוש ב-3 סוללות AAA 900mAh, עם פתיחה וסגירה 3 פעמים ביום.
- טמפרטורת אחסון: 20°C - עד 50°C.
- טמפרטורת הפעלה: 5°C עד 45°C.

שמרו את הוראות ההפעלה לשימוש עתידי.

מאפיינים - מנעול ללא מפתח

- מנעול ללא מפתח. כלול 2 כרטיסי מפתח.
- אפשרות לשימוש בכרטיס נוסף התומך בטכנולוגיית NFC/RFID
- התרעת מתח הסוללות נמוך.

הוראות שימוש

- התקינו את המנעול ואת לוחית המנעול בהתאם להוראות ההרכבה.
- בדקו ששני כרטיסי מפתחות המאסטר יכולים להפעיל את המנעול לאחר הכנסת הסוללות.
- מומלץ לשמור את אחד מכרטיסי המאסטר במקום בטוח כמפתח חליפתי.

שימו לב - אין להשיג כרטיסים חליפיים באיקאה.

שימוש בכרטיסים אחרים

- יתכן שניתן יהיה להשתמש בכרטיס נוסף (למשל, כרטיס ספרייה, כרטיס מועדון וכרטיס לתחבורה ציבורית) התומך ב-NFC/RFID בתור מפתח.
- הדלת/מגירה צריכות להיות פתוחות כשאתם מגדירים כרטיס נוסף. פתחו בעזרת כרטיס מפתח המאסטר שלכם והוסיפו את המפתח הנוסף על ידי הצבתו על אזור הקריאה.

יצרן: IKEA of Sweden AB

כתובת:

Box 702, SE-343 81 Älmhult, SWEDEN



סימן המיחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למיחזור בהתאם לחוקים המקומיים. כשאתם ממיינים פסולת, אתם עוזרים להפחית את כמות האשפה המצטברת ולהקטין את ההשפעות המזיקות על האדם והסביבה. לקבלת מידע נוסף, פנו לחנות איקאה.

איפוס:
להסיר סוללות.

אזהרה

במוצר זה יש לעשות שימוש רק בסוללות AAA/HR03 מהסוג הבא: LADDA 900 (1.2V, 900mAh, Ni-MH), LADDA 500 (1.2V, 500mAh, Ni-MH), סוללות אלקליין או סוללות אבץ פחם.

אין לערבב סוללות עם קיבולות, סוגים או תאריכי תפוגה שונים.

שירות מוצרים

אין לנסות לתקן מוצר זה בעצמכם.

מפרט טכני:

סוג: E1778 ROTHULT

קלט: 3 סוללות מסוג AAA/HR03

שימוש בחלל סגור בלבד

תדר פעולה: 13.56 MHz

הספק פלט: עד 50.9 dbm ל-3 מטרים

