

SEGERÖN

Design Sarah Fager



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

This product has been tested for contract use.

Cleaning: Wipe clean with a mild soapy solution.

We recommend to not clean rope or metal furniture with a strong cleaning agent or an abrasive material since it may discolour or damage the surface.

Maintenance: Maintenance-free.

Storing: If possible, store your outdoor furniture in a dry and cool place indoors. When stored outside, tilt the furniture and preferably use water-repellent covers. Make sure air can circulate to avoid moisture build-up. In freezing temperatures, plastic can weaken and is not recommended for use.

Repair: The steel is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

NOTE!

To maintain the stability of your furniture, re-tighten the screws at least once per season.

חשיבותו! בתשומת לב ושמרו לעינן בעתיד

מוצר זה נבדק לשימוש במקומות ציבוריים.

תיקיון: נגבו במלילית רטובה עם תמייסת סבון עדינה. מומלץ להימנע מניקוי רהיטי מתכת או ריהוט בשילוב חבלים עם חומר ניקוי חזק או חומצה מחייב לשינויים בצע ה מוצר או פגעה בפני השטח של המוצר.

תחזוקה: לא תחזקה.

מומלץ לאחסן את ריהוט הגן במקום יבש וקריר בתוך הבית. במידה וריהוט הגן מאוחסן בחוץ, הקפידו להטוט את הרהיטים והעדיפים לשימוש בכיסויים עמידים בפני מים. ודאו כי פתחי האוורור אינם חסומים כדי למנוע הצטברות לחות. טמפרטורות מוקפיאות עשויות להחליש את חומר הפלסטייק.

תיקון: הפלדה מוגנת מחלודה באמצעות ציפוי אבקה של צבע פלסטי. אם הציפוי מתפרק מסיבה כלשהי, הפלדה אינה מוגנת ועלולה להיווצר חלוודה. לתקן הנזק, נקנו וצבעו מחדש.

שימוש לבן!

כדי לשמר על יציבות הרהיט, יש לוחזק את כל הברגים והחיבורים לפחות אחת לתקופה.