

SEGERÖN

Design Sarah Fager



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

This product has been tested for domestic use.

This outdoor furniture requires no maintenance.

However, by keeping the furniture clean and storing it properly you can enjoy it year after year.

Cleaning: Wipe clean with a mild soapy solution.

We recommend to not clean rope or metal furniture with a strong cleaning agent or an abrasive material since it may discolour or damage the surface.

Maintenance: Maintenance-free.

Storing: If possible, store your outdoor furniture in a dry and cool place indoors. When stored outside, tilt the furniture and preferably use water-repellent covers. Make sure air can circulate to avoid moisture build-up. In freezing temperatures, plastic can weaken and is not recommended for use.

Repair: The steel is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

NOTE!

To maintain the stability of your furniture, re-tighten the screws at least once per season.

עברית

חשוב! קראו בתשומת לב ושמרו לעיון בעתיד

מוצר זה נבדק ונמצא מתאים לשימוש ביתי.

ריהוט גן זה אינו דורש תחזוקה. יחד עם זאת, באמצעות שמירה על ניקיון הריהוט ואחסון נכון תוכלו ליהנות ממנו שנים רבות.

ניקיון: נגבו במטלית רטובה עם תמיסת סבון עדינה. מומלץ להימנע מניקוי רהיטי מתכת או ריהוט בשילוב חבלים עם חומר ניקוי חזק או חומצה מחשש לשינויים בצבע המוצר או פגיעה בפני השטח של המוצר.

תחזוקה: ללא תחזוקה.

מומלץ לאחסן את ריהוט הגן במקום יבש וקריר בתוך הבית. במידה וריהוט הגן מאוחסן בחוץ, הקפידו להטות את הרהיטים והעדיפו להשתמש בכיסויים עמידים בפני מים. ודאו כי פתחי האוורור אינם חסומים כדי למנוע הצטברות לחות. טמפרטורות מקפיאות עשויות להחליש את חומר הפלסטיק.

תיקון: הפלדה מוגנת מחלודה באמצעות ציפוי אבקה של צבע פלסטי. אם הציפוי מתקלף מסיבה כלשהי, הפלדה אינה מוגנת ועלולה להיווצר חלודה. לתיקון הנזק, נקו וצבעו מחדש.

שימו לב!

כדי לשמור על יציבות הרהיט, יש לחזק את כל הברגים והחיבורים לפחות אחת לתקופה.