

# TOSTERÖ

## English

TOSTERÖ cover is waterproof and protects your outdoor furniture from rain, snow, sun, dirt, dust and pollen when not in use. Protecting your outdoor furniture with a waterproof cover is an easy and effective way to keep it looking fresh and new for longer, before any maintenance is needed.

### HOW TO USE

Note! The cover is not reversible. The glossy side must always face inwards, towards the furniture. Make sure the furniture is dry. After putting the cover over the furniture, fasten the hook-and-loop straps around the legs to ensure the cover stays in place on windy days. Then adjust the bottom hem so the lower parts of the furniture are properly covered.

Store your outdoor furniture in a cool dry place indoors during the off-season. If it must stay outdoors, cover it and place it under a roof and on a dry and protected floor or surface to prevent moisture and mildew from penetrating the wood from below. If you are not able to place the covered furniture under a roof, make sure water can run off by tilting the furniture slightly. After a rain or snowfall, wipe off excess water or snow – especially from flat surfaces. Allow air to ventilate, to avoid moisture and mould.

### CARE INSTRUCTIONS

To clean the cover from dust and dirt, spray it with cold water (30°C) from a garden hose or wipe it with a soft cloth soaked in water. For heavily soiled areas, scrub with a sponge soaked in mild detergent and rinse with cold water.



Design and Quality  
IKEA of Sweden

## עברית

TOSTERÖ כוסיו עמיד בפני מים ומגן על רהיטי החוץ מפני נזקי הגשם, השמש, השלג, וכמו כן מפני לכלוך ואבק, כאשר אינם בשימוש. הודות לכיסוי העמיד בפני מים, תוכלו לשמור על מראם הרענן והחדש של רהיטי החוץ לאורך זמן רב בקלות וביעילות, לפני שיהיה צורך לטפל בהם.

### הוראות שימוש

שימו לב! יש להשתמש בכיסוי כאשר צדו המבriק מופנה כלפי פנים ולכיוון הרהיטים.

וודאו שהרהיטים יבשים לפני שאתם מכסים אותם. אחרי ששמתם את הכיסוי מעל הרהיטים, הדקו את רצועות הלולאה סביב הרגליים כדי להבטיח שהכיסוי יישאר במקומו במזג אוויר סוער. לאחר מכן, וודאו שגם חלקם התחתון של הרהיטים מכוסה כראוי.

במהלך העונה הקרה, יש לאחסן את ריהוט החוץ במקום קריר ויבש בבית. המידה ועל הרהיטים להישאר מחוץ לבית, כסו אותם ומקמו תחת קורת גג על רצפה או משטח יבש ומוגן כדי למנוע מהיווצרות רטיבות ועובש. אם אתם לא יכולים למקם את הרהיטים תחת קורת גג, הטו את הרהיטים בכדי לוודא כי מים לא יצטברו עליהם. במידה והיה גשם או שלג, נגבו את המים או השלג שהצטברו על הרהיטים- בעיקר על גבי ממשטחים שטוחים. אוררו כדי להימנע מהיווצרות לחות ועובש.

### הוראות טיפול

התיזו מים קרים (30 מעלות צלסיוס) על הכיסוי בעזרת צינור השקיה או נקו עם מטלית רכה וספוגה במים על מנת לנקות אותו מאבק ולכלוך. במידה והכיסוי מלוכלך מאוד, יש לקרצף אותו בעזרת ספוגית הספוגה בחומר ניקוי עדין ולשטוף עם מים קרים.