



TRIXIG




Design and Quality
IKEA of Sweden


1




2




3





4



5



6



English



Caution! Recycling of built-in batteries. Make sure that the battery is discharged before removal. Use caution to avoid damaging the battery.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.

עברית



זהירות! מיחזור סוללות מובנות. הסרת סוללות מובנות תתבצע על ידי איש מקצוע מוסמך בלבד. יש לנקוט בזהירות על מנת למנוע נזק לסוללה.



סימן המחזור מראה שיש להשליך את המוצר בנפרד מהפסולת הביתית. יש להעביר אותו למחזור בהתאם לחוקים המקומיים. באמצעות הפרדת מוצר זה מן הפסולת הביתית, תעזרו להפחית את כמות הפסולת המועברת למשרפות או מטמנות ולמזער את ההשפעה השלילית על בריאות האנשים והסביבה. לקבלת מידע נוסף, אנא צרו קשר עם חנות איקאה הקרובה לביתכם.