



Design and Quality
IKEA of Sweden

English

IMPORTANT RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

This product has been tested for domestic use.

*This outdoor furniture requires no maintenance.
However, by keeping the furniture clean and storing it
properly you can enjoy it year after year.*

Clean: Wipe clean with a mild soapy solution. It is not recommended to clean plastic or metal furniture with a strong cleaner or an abrasive material because it may discolour or damage the surface.

Maintenance: Maintenance-free.

Storing: If possible, store your plastic outdoor furniture in a dry and cool place indoors. When stored outside, tilt the furniture and preferably use water-repellent covers. Make sure air can circulate to avoid moisture. In freezing temperatures, plastic can weaken and is not recommended for use.

Repair: The steel is protected from rust with a powder coating of plastic paint. If for some reason the coating comes off, the steel is not protected and rust may occur. To repair the damage, wipe clean and repaint to restore protection.

NOTE!

To increase the stability of your furniture, re-tighten the screws at least once per season.

חשיבותם של ריהוט גן בהתשומת לעינן בעתיד

מוצר זה נבדק ונמצא מתאים לשימוש ביתי.

ריהוט גן זה אינו דורש תחזוקה. עם זאת, שמירה על ניקיון הרהיט ואחסון ראווי יאפשרו לכם להנוט ממנו שנה אחר שנה.

ניקיון: נגבו באמצעות מטילת עם נוזל ניקוי עדין. לא מומלץ לניקות ריהוט מפלסטיק או מתקצת עם חומר ניקוי חזק או חומר שורט כיוון שהם יכולים לגרום לשינוי בצבע או לפגוע במשטח.

תחזוקה: ללא תחזוקה.

אחסון: במידת האפשר, יש לאחסן את ריהוט הגן מפלסטיק במקום קרייר ויבש בתוך הבית. אם מאחסנים בחוץ, יש להטות את הרהיטים ולהשתמש בכיסויים דוחים. יש לוודא כי הרהיטים מאוזרים כדי למנוע הצטברות מים. יש לטמפרטורות קפואות, פלסטיק עשוי להיחלש ואני מומלץ לשימוש.

תיקון: הפלדה מוגנת מחלודה באמצעות ציפוי אבקה של צבע פלסטי. אם הציפוי מתפרק מסיבה כלשאי, הפלדה אינה מוגנת ועלולה להיווצר חלודה. לתקן הנזק, נקנו וצבענו מחדש.

שימוש לבן!
כדי להגבר את יציבות הרהיטים, חזקו את הברגים לפחות אחת לעונה.

