

English	4
עברית	4

English

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE



WARNING

- DO NOT place this product near a window as it can be used as a step by the child and cause the child to fall out of the window.
- Be aware of the risk of open fires and other sources of strong heat in the vicinity of the product.
- DO NOT place this product near a window where cords from blinds or curtains could strangle a child.

Important safety information

- Complies with EN 17191:2021.
- Check all fittings regularly and tighten if necessary.
- DO NOT use if any part is broken, torn or missing. Contact your local IKEA store for replacement parts. Do not substitute parts.
- Recommended for children between 3-7 years old.

Care and cleaning

- · Wipe clean with a cloth damped in a mild cleaner.
- · Wipe dry with a clean cloth.

עברית

חשוב! קראו בתשומת לב ושמרו לעיון בעתיד



- אין למקם מוצר זה בקרבת חלון בשל חשש לשימוש בו כמדרגה לילד וכתוצאה מכך סכנת נפילה מהחלון.
 - שימו לב לסכנות הנובעות מאש גלויה ומקורות חום אחרים בסביבה הקרובה למוצר.
- י אין למקם את את המוצר ליד קיר שמשתלשלים ממנו חוטים לוילון, העלולים להוות סכנת חנק.

הוראות בטיחות חשובות

- .EN 17191:2021 תואם לתקן •
- יש לוודא הידוק כל הברגים והחיבורים בקביעות ולחזק במידת הצורך.
- אין להשתמש במוצר זה באם חסר חלק כלשהו או אם חלק שבור, פגום או חסר. אין להשתמש בחלקים שאינם של IKEA.
 - מומלץ לגילאים 3-7 שנים.

הוראות טיפול וניקוי

- נקו בעזרת מטלית וחומר ניקוי נוזלי.
 - נגבו לייבוש בעזרת מטלית רכה.