

VARDAGEN



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

Before first use

- Before using this product for the first time, wash, rinse and dry thoroughly.

Cleaning

- The cookware is best washed by hand after use. Use hot water and washing-up detergent. Dry carefully after cleaning.
- Do not use steel wool or anything that can scratch the surface of the cookware.

Good to know

- This cookware is suitable for use on all types of hobs and in the oven.
- Bear in mind that the handles get hot when the cookware is in use. Always use pot holders when moving the cookware and lifting the lid.
- Never let the cookware boil dry, as this can damage the enamel coating and cause the base of the cookware to warp.
- Do not expose the cookware to heavy variations in temperature, e.g. by moving it from the fridge directly to the cooker, due to the risk of cracking.
- Be careful not to hit or drop the cookware against a hard surface, because then the cookware or the enamel can break.
- Always lift the cookware when moving it on a glass ceramic hob to avoid the risk of scratching the hob.
- Use the cookware on a hob of the same or smaller diameter to save energy.
- If you have any problem with the product, please, contact your nearest IKEA store/ Customer Service or see www.ikea.com.

לפני השימוש הראשון

- לפני השימוש הראשוני במוצר זה, יש לשטוף את המוצר באופן ידני לייבוש היטב.

הוראות ניקוי

- מומלץ לנקות את הכלי ידנית לאחר השימוש. השתמשו במים חמים וסבון נוזלי. השאירו את הכלי לייבוש.
- אין להשתמש בצמר פלדה או כל תכשיר ניקוי העלול לשרוט את שטח הפנים של הכלי.

טוב לדעת

- כלי בישול זה מתאים לשימוש בתנור ועל כל סוגי כיריים.
- זכרו כי הידיות מתחממות בעת השימוש. היעזרו תמיד בכפפות לסירים בעת הזזת הכלים או הרמת המכסה.
- לעולם אל תניחו לכלי הבישול לרתוח יתר על המידה, מכיוון שהבסיס עלול להתכווץ והציפוי עשוי להתקלף.
- אין לחשוף את הכלי לשינויים קיצוניים בטמפרטורה, למשל, על ידי העברתו מהמקרר ישירות אל הכיריים. הדבר עלול לגרום לסדקים בכלי.
- יש להימנע מפגיעות בכלי או מהנחתו בחוזקה על משטח קשיח, היות שהדבר עלול לגרום לכלי או לציפוי האמאייל להישבר.
- יש להרים את כלי הבישול בעת העברתו על כיריים, כדי למנוע את הסיכון לשריטות על גבי הכיריים.
- השתמשו בכלים על כיריים באותו קוטר או בקוטר קטן יותר על מנת לחסוך באנרגיה.
- בכל מקרה של שאלה או בעיה בנוגע למוצר, אנא צרו קשר עם שירות הלקוחות של חנות IKEA, או היכנסו לאתר www.ikea.com.