

# VARDAGEN

## ENGLISH

### **Before first use**

- Wash with washing-up liquid and rinse with water before using for the first time.

### **How to use**

The tin does not have a non-stick coating. Grease before use to make it easier to turn goods out after baking.

Placing the tin on an oven tray makes it easier to put it into the oven without spilling or burning yourself.

Use wooden or plastic utensils without sharp edges only.

The tin is not suitable for acidic foods.

The tin is handwash only.



Design and Quality  
IKEA of Sweden

## **עברית**

### **לפני השימוש הראשון**

— יש לנקות בחומר ניקוי ולשטוף היטב במים לפני השימוש הראשון.

### **אופן השימוש**

התבנית אינה כוללת ציפוי מונע הידבקות. יש לשמן את התבנית לפני השימוש על מנת שיהיה קל יותר להפוך את המזון לאחר האפייה.

הניחו את התבנית בתוך מגש כדי להכניס אותה ביתר-קלות לתנור מבלי שדבר מה יישפוך או שתיכוו.

מומלץ להשתמש בכלי פלסטיק או עץ ללא שוליים חדים בלבד.

התבנית אינה מתאימה למאכלים חומציים.

יש לשטוף את התבנית ביד בלבד.