

VARDAGEN



Design and Quality
IKEA of Sweden

English

3

עברית

4

English

Before first use

- Before using this product for the first time, wash, rinse and dry thoroughly.

Cleaning

- The cookware is best washed by hand after use. Use hot water and washing-up detergent. Dry carefully after cleaning.
- Do not use steel wool or anything that can scratch the surface of the cookware.

Good to know

- This cookware is suitable for use on all types of hobs and in ovens.
- Use the cookware on a hob of the same or smaller diameter to save energy.
- Bear in mind that the handles get hot when the cookware is in use. Always use pot holders when moving the cookware and lifting the lid.
- Always lift the cookware when moving it on a glass hob or ceramic hob. Do not pull it across the hob due to the risk of scratching.
- Do not expose the cookware to heavy variations in temperature, e.g. by moving it from the fridge directly to the cooker, due to the risk of cracking.
- Be careful not to hit or drop the cookware against a hard surface, because then the cookware or the enamel can break.
- If you have any problem with the product, please, contact your nearest IKEA store/ Customer Service or see www.ikea.com.

לפני השימוש הראשון

- לפני השימוש הראשוני במוצר זה, יש לשטוף את המוצר באופן ידני לייבוש היטב.

הוראות ניקוי

- מומלץ לנקות את הכלי ידנית לאחר השימוש. השתמשו במים חמים וסבון נוזלי. השאירו את הכלי לייבוש.
- אין להשתמש בצמר פלדה או כל תכשיר ניקוי העלול לשרוט את שטח הפנים של הכלי.

Good to know

- כלי זה מתאים לשימוש על כל סוגי הכיריים, ובטוח לשימוש בתנור.
- מומלץ להשתמש בכלי על כיריים בקוטר זהה או קטן יותר, כדי לחסוך אנרגיה.
- יש לזכור כי הידיות יכולות להתחמם מאוד בעת השימוש. על כן מומלץ להשתמש בכפפות לתנור בעת העברת הכלי, או בעת הסרת המכסה.
- כאשר משתמשים בכיריים מזכוכית, יש להרים את הכלי בכל פעם שרוצים להעבירו כדי לא לשרוט את הכיריים.
- אין לחשוף את הכלי לשינויים קיצוניים בטמפרטורה, למשל, על ידי העברתו מהמקרר ישירות אל הכיריים. הדבר עלול לגרום לסדקים בכלי.
- יש להימנע מפגיעות בכלי או מהנחתו בחוזקה על משטח קשיח, היות שהדבר עלול לגרום לכלי או לציפוי האמאיל להישבר.
- בכל מקרה של שאלה או בעיה בנוגע למוצר, אנא צרו קשר עם שירות הלקוחות של חנות IKEA, או היכנסו לאתר www.ikea.co.il.