





ANKARUDDEN



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.






NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.




www.IKEA.com/secure-it


A




Ø 8 mm (5/16'')




B



Ø 8 mm (5/16'')









C




Ø 3 mm (1/8'')





1



118331

20x



105248

4x



146114

24x




101345

24x



1009796


20x



153548


5x

2




10096669

16x



130449

16x



118331

12x




146114

24x



101345

8x



10040242

4x





1009796

12x




120076


32x




1




2






3




4




5




6





7




8




1x




9




10




11




12






13




14




15




16




17




18




19




20




21




22






23





24






26




27






www.IKEA.com/secure-it






www.IKEA.cn/secure-it




28


English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.









29






30






30









29





31









32




33




34




35




36




37




38




39




40





41



42



43



3x

