


BESTÅ



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:





ALWAYS install anti-tip device provided.



NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

ALWAYS secure your television with an anchor device.

English

Read and follow each step of the instruction carefully.






130618

16x



118137
122971
141028
130725
119253

8x



130619
130722
141027
130723
130620

8x




109049

4x




113287

8x




116637

12x




144342

4x




103693

4x




144343
144344
144345
144346
144347

4x




100006

1x




114947
115988


8x




6x




6x




2x





1x




1x




1x




1




2




3




4




5




6





7




8




4x




9




10





11







12








14












17






18







19







1



2




3





BESTÅ



IKERÅ

