


BLÅLIDEN



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.










Place heaviest items in the lowest drawers.

English






Read and follow each step of the instruction carefully.







1




2




1




2




3




4




5







7




8




9




10







11





12








13




14





15




16




17




18



19



20



21

