

BRIMNES



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.


Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.









2x




2x




2x



4x




4x




2x


1




2




3




4




5




6




7




8




9




10




11











12






14









17





18







19









22



16x




128643




133224


23




24




25




26



27



28



29

