


BRIMNES



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.















English

Read and follow each step of the instruction carefully.






1




2




117877

8x



117878




8x






130508
130509

2x


1




2




3




4




5




6





7




8




9




10




11




12




13




14




15




16




17







19




20






21




22




23







24




25




26




27



28



29



30

