


# EKENABBEN



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.






105107

20x



10074728

20x




107862

4x



101343

40x




109560

2x




100823

2x




100001

1x




102720


2x




1




# 2





# 3



4




5









6




7











9








10





9





10

