


# EKET



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**





ALWAYS install anti-tip device provided.



NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.






8x




8x




8x




8x




8x



2x




2x




2x



2x




4x








2x




1




1



2




3







4




5




6




7







8






9










# 12








13


















15









AA-1908785




AA-1908785




17






18




# 19




# 20







22



23







# 25

