


# EKET



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.



NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.







12x




12x




2x




2x



2x









2x




1x


1




# 2




# 3




4




5



6




7










8



9










**11**





**12**







# 13








14




15









16





17








AA-1908823



AA-1908823



AA-1908823





