


EKET



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:





ALWAYS install anti-tip device provided.


NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.


NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.






4x




4x



3x




1x




2x




2x




2x




2x




1x




1x




1x




1x



2x









2x




1x


1




2




3




4




5




6






7




8











10









11

11








12








13















15





16








17



20



21

