


EKET



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:





ALWAYS install anti-tip device provided.


NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.

NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.







4x




4x




3x




1x




2x




2x




2x




2x



1x




1x




1x

155197




1x

155198




2x

10119673









2x




1x


1




2




3




4




5




6




7





8





9







10








11





11







12









13




14












15




16











AA-2693474



AA-2693474




17




1x

10119600




10119658
10119673




1x

10119600




10119658
10119673


18



19



20



21

