


FÄRJKARL



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.


Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.









126916

2x




150688

2x




150689

2x




10116964

2x




128711

4x




123746

2x




120171

4x




123772


2x




1




2




3




4




5




6





7






8






9




10




11




12




13




14




15




16







17






19









21




22




23




24






25

















27



28







30

