





HAUGA



Design and Quality
IKEA of Sweden



English

WARNING!

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.


Place heaviest items in the lowest drawers.

Read and follow each step of the instruction carefully.







2x




2x




1x



2x




1x



1x


370173

1




10050771

4x




10050769

4x




151706
151708

2x




151705
151707

2x




101359

2x



101345

21x



10093081

10x



10093082

10x




105811

4x




146114
1004962

18x




153548
158568

2x



10040039
10051022

2x




155370

1x

A




12x




6x




18x




12x




10x




24x




6x




3x




1




2




3




4




5




6




7




8




9




10




11




12






13




14




15




16




17




18




19




20






21




22







23



24




25






www.IKEA.com/secure-it



www.IKEA.cn/secure-it



26



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.




A
Ø 8 mm (5/16")
1
2
3


B
Ø 8 mm (5/16")
1
2
3





C
Ø 3 mm (1/8")
1
2
3





↕
27























32





33





34






35


36




37




38




39




40




41



42




43






1



2



3

