



HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.

NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.




NEVER open more than one drawer at a time.






DO NOT defeat or remove the drawer interlock system; it is an important stability and safety system.

Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.





109048

2x



10087223

2x




109049

1x




100823

2x



1x

10102070




106989


1x

370173


1



4x



2x



13x




4x




18x




2x




12x




12x




6x




6x




2x



2x



2x




2x

2




144575

8x



144574


8x



10049270


2x

A



118331

12x




119976

6x



146114


18x



145718


159553

12x



101345


10x



119030


118224

24x




10052019

6x




10040242


3x




1




2




3




4




5




6




7




8




9




10




11




12




13




14




15




16




17




18







19




20











23






24








25








26



27






www.IKEA.com/secure-it



www.IKEA.cn/secure-it




28

English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")






1







2












↕
29





















32





33



34







2x




35




36




37




38




39




40



41



42



43

