



HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English


Read and follow each step of the instruction carefully.





2x

106989




109049

2x




100823

4x



109048

2x



121714











2x



17

326949


1




2




8x




8x




2x



A




12x




6x




18x




12x




10x




24x




6x




3x







1




A collection of 10 mechanical parts for assembly, including a long threaded rod, a short threaded rod, two screws, a washer, a nut, a U-bolts, a U-bolts with a nut, a U-bolts with a nut and washer, a U-bolts with a nut and washer, and a U-bolts with a nut and washer.




2




3




4




5




6




7




8





9




10




11




12







13




14










15











16








17









18




19




20




21




22







23




24




25




26




27





28






29





30








www.IKEA.com/secure-it




www.IKEA.cn/secure-it



English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


A




Ø 8 mm
(5/16")




1




2



3




B




Ø 8 mm
(5/16")




1




2



3




C




Ø 3 mm
(1/8")



1




2




3








32




33







35




35




36




36







37




38




39




40




41




42



43



44



45

