



HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






A



118331

12x




119976

6x




146114

18x




145718
159553

12x




101345

10x




119030
118224
120076

24x




10052019

6x




10040242

3x




33

1



151708

14x




151707

14x




146114

18x




10093081

6x




10093082

6x




101345

12x



153548
158568

4x




10040039
10051022

4x




10051650
10051660

16x



10039873

4x




10039878

4x




105811

4x




10052019

2x




119976

2x




133303
190586

2x




7

2




144574
10051084

4x





10050715
10042135
10070233


4x




32




1




2




3




4




5




6




7




8





9









11




12





13






14











16










18







19




20






21









English



The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.







22






22





23


16x




24




25









27




28







29




4x








30




30




31




31




32



32






2x






33


34




35




36




37




38




39





41



42

