




# HAVSTA



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover. To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.






NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.

English

Read and follow each step of the instruction carefully.







2x




2x



2x




4x




2x

371505

# 1



2x



7x



4x



21x




25x



24x




24x



1x

# 2




8x



8x




8x




10x




10x



2x



2x




5x

# 3




194867

6x



10091382

6x




123492

24x




110630

24x



10095420

24x




119030

24x




101345

20x




10040242

12x





190459

1x




10127303


6x



# 3




# 4







# 5




# 6




7




8




9




# 10




# 11




12




13








15




16



17




18







# 19




# 20




21




22







# 24




# 25




26




27




28




29




30





31






32







33





34







35




36



37






[www.IKEA.com/secure-it](http://www.IKEA.com/secure-it)






[www.IKEA.cn/secure-it](http://www.IKEA.cn/secure-it)





# 38

## English


The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.










40




41








**42**




**43**









**44**




**45**




**46**




47




48




49




50




51




52



53



54



55

