



# HAVSTA



Design and Quality  
IKEA of Sweden



English

## WARNING

**Children have died from furniture tipover.**

**To reduce the risk of furniture tipover:**

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.




NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.





NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.






2x




2x



2x



4x



2x

# 1




100214

2x



109540

7x



139615

4x



118331

21x



113434

122332

25x




101350

24x



117186

24x



100092

1x

# 2



118331

8x



113434

8x



101350

8x




144574

10x



144575

10x




159991

159992


10101154

2x



153549

2x



108255


5x

# 3




194867

6x



10091382

6x




139615

24x



110630

24x



10095420

24x




119030

24x




101345



20x




10040242

4x







3




4




5




6




7




8




9




# 10




# 11




12




13





# 14




# 15




# 16




17




18




19




20




# 21




# 22




# 23




# 24




# 25




# 26




# 27




# 28




# 29




30





31







**32**




# 33





# 34






35




# 36



# 37

x


x





www.IKEA.com/secure-it

www.IKEA.cn/secure-it




# 38

**English**

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.

**A**




**Ø 8 mm**  
**(5/16")**



**1**




**2**




70 mm  
(2 3/4")


**3**




**B**




**Ø 8 mm**  
**(5/16")**



**1**




**2**




≈ 30 mm  
(≈ 1 1/4")

**3**




**C**




**Ø 3 mm**  
**(1/8")**



**1**



**2**





≈ 30 mm  
(≈ 1 1/4")

**3**





39









40





41









**42**








**43**

**44**








45




46




# 47




# 48






# 49




50




51




52



53



54



55

