


KALLAX



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.










NEVER open more than one drawer at a time.



Place heaviest items in the lowest drawers.

English



Read and follow each step of the instruction carefully.









1




2




3




4




5




6




7




8




9




10




11




12




13




14







16




17






18







19






20







21




22






23










20



21



22



23

